


MANIFOLD

User Manual V1.0

2015.11



Searching for Keywords

Search for keywords such as “battery” and “install” to find a topic. If you are using Adobe Acrobat Reader to read this document, press Ctrl+F (Windows) or Command+F (Mac) to begin a search.


Navigating to a Topic

View a complete list of topics in the table of contents. Click on a topic to navigate to that section.

Legends

 Warning

 Important

 Hints and Tips

 Reference

Disclaimer

Thank you for purchasing the DJI Manifold (abbreviated as “Manifold”). Users must comply with local radio transmission laws and regulations when using this product. By using this product, you hereby agree to this disclaimer and signify that you understand all points completely. Please use this product in strict accordance with the manual and be sure to pay attention to the warnings. When assembling and using this product, follow all instructions carefully. SZ DJI TECHNOLOGY CO., LTD. and its affiliated companies assume no liability for damage(s) or injuries incurred directly or indirectly from improper use of this product.

DJI is the registered trademark of SZ DJI TECHNOLOGY CO., LTD. (abbreviated as “DJI”). Names of products, brands, etc., appearing in this manual are trademarks or registered trademarks of their respective owner companies. This product and manual are copyrighted by DJI with all rights reserved. No part of this product or manual shall be reproduced in any form without the prior written consent or authorization of DJI.

This disclaimer is produced in various languages. In the event of divergence among different versions, the Chinese version shall prevail when the product in question is purchased in Mainland China, and the English version shall prevail when the product in question is purchased in any other region.

Contents


Disclaimer	2
Product Profile	4
Connector View	4
System Settings	8
Basic Setup	8
Root Password	8
Network Settings	8
Max Performance Mode	9
Installing Development Packages	9
Installing CUDA	9
Installing the OpenCV4tegra	9
Installing the Robotic Operating System (ROS)	10
System Image	10
Downloading Package File	10
Entering Recovery Mode	10
Create a System Image	11
Restoring the System Image	12
Compiling Kernel	12
Specification	13

Product Profile

The Manifold is an embedded-Linux computer that is ideal for DJI SDK based software and application development on DJI flight platforms including the DJI Matrice 100. Featuring an NVIDIA Tegra K1 SOC (CPU+GPU+ISP in a single chip) with both standard and extended connectors and interfaces, the Manifold development board provides high flexibility and extensibility for developers.


Connector View

Connector Overview




Expansion Header

The expansion header provides an interface to customized devices.




The table below describes the pins and voltages of the expansion header.

Pin #	Signal	Voltage	Pin #	Signal	Voltage
1	3.3V_SYS	3.3 V-Power	14	GPIO2_OUT	3.3 V
2	SPI4_CS3_L	1.8 V	15	UART1_TXD_CON	3.3 V
3	3.3V_SYS	3.3 V-Power	16	GND	0 V
4	SPI4_SCK	1.8 V	17	NULL	-
5	1.8V_VDDIO	1.8 V-Power	18	PWR_I2C_SCL	1.8 V
6	SPI4_MOSI	1.8 V	19	GND	0 V
7	1.8V_VDDIO	1.8 V-Power	20	PWR_I2C_SDA	1.8 V
8	SPI4_MISO	1.8 V	21	UART4_RXD_CON	3.3 V
9	NULL	-	22	GEN1_I2C_SCL	1.8 V
10	SPI4_CS0_L	1.8 V	23	UART4_TXD_CON	3.3 V
11	GND	0 V	24	GEN1_I2C_SDA	1.8 V
12	GPIO1_IN	3.3 V	25	GND	0 V
13	UART1_RXD_CON	3.3 V	26	GND	0 V

- 
- Access UART1 from `/dev/ttTHS0` in the operating system. UART4 is used as a kernel console and it is mapped to `/dev/ttyS0`.
 - I2C is running at these frequencies 100kHz/400kHz (Standard/Fast Mode). Access GEN1_I2C from `/dev/i2c-0` in the kernel. Access PWR_I2C from `/dev/i2c-4` in the kernel.
 - The maximum SPI frequency is 50MHz.
 - Access GPIO1_IN from `/sys/class/gpio/gpio157` and GPIO2_OUT from `/sys/class/gpio/gpio158` in the kernel.

UART 2/UART 3 Port


Both ports are used to establish a connection with the Matrice 100.



UART 2 Port Description

Pin #	Signal	Voltage	Pin #	Signal	Voltage
1	NULL	-	4	GND	0 V
2	NULL	-	5	TXD	3.3 V
3	NULL	-	6	RXD	3.3 V

- ⚠
- Access UART2 from `/dev/ttyTHS1` in the kernel.




UART 3 Port Description

Pin #	Signal	Voltage	Pin #	Signal	Voltage
1	NULL	-	3	TXD	3.3 V
2	RXD	3.3 V	4	GND	0 V

- ⚠
- Access UART3 from `/dev/ttyTHS2` in the kernel.


CAM_IN and CAM_OUT Port

The CAM_IN and CAM_OUT ports mainly serve as the interface between the camera mounted on the Matrice 100 and the Manifold. Refer to the Manifold product page (<https://developer.dji.com/manifold/videos/>) for details on how to connect the camera to the Manifold.



Recovery USB

The Recovery USB port can work in either Host or Slave Mode, but is set to Host Mode by default. In Slave Mode, you can connect the Manifold to a computer via the Recovery USB port to create a system image. Refer to “[System Image](#)” on P10 for more information on how to create a system image.



The Recovery USB works in Host Mode by default. Execute the following commands to switch from Host Mode to Slave Mode.

```
$ echo 0 > /sys/devices/platform/tegra-otg/enable_host
$ echo 1 > /sys/devices/platform/tegra-otg/enable_device
```

Mount the USB Gadget using the commands below if necessary. Take `g_zero` for example:

```
$ modprobe g_zero
$ echo connect > /sys/devices/platform/tegra-udc.0/udc/tegra-udc.0/soft_connect
```

Execute the following commands to switch from Slave Mode to Host Mode.

```
$ echo disconnect > /sys/devices/platform/tegra-udc.0/udc/tegraudc.0/soft_connect
$ modprobe -r g_zero
$ echo 0 > /sys/devices/platform/tegra-otg/enable_device
$ echo 1 > /sys/devices/platform/tegra-otg/enable_host
```



- The CAM_IN and Recovery USB ports are both governed by the same USB controller, and hence only one port can be used at a time.

System Settings

Set the root password and the networking and system parameters in the terminal after the system is booted up. This chapter describes the procedures on configuring these settings.

Basic Setup

The Manifold development board should be connected to an HDMI monitor, a USB keyboard and mouse, and an Ethernet connection (optional). The Ubuntu 14.04 operating system will sign in automatically after the Manifold is powered on. Enter the following login credentials if necessary:

User name: ubuntu

Password: ubuntu

Root Password

A random root password is assigned. If a static root password is required, run the following command:

```
$ sudo passwd
```

And enter the login password “**ubuntu**” then enter the root password.

Network Settings

Ethernet Settings

Plug the Ethernet cable into the Ethernet port. If DHCP service is available on the connected network, then the Manifold will be assigned with an IP address automatically. Otherwise, run the following command to obtain an IP address:

```
$ sudo ifconfig eth0 xxx.xxx.xxx.xxx
$ ifconfig
```

where “xxx.xxx.xxx.xxx” is the IP address that you wish to use.

Wireless Network

It is recommend to use the mini-PCIe chipet with ““Intel 7260 HMW”” wireless adapter, which supports both 802.11n and 802.11ac protocols. The drivers for the Intel 7260 HMW is preinstalled. Refer to http://elinux.org/Jetson/Network_Adapters for more information about how to configure wireless adapters from other vendors.

Wireless Settings

Wireless adapter will acquire an IP address if DHCP services is available on the connected network. Should there is a need to manually assign an IP address to the wireless adapter, run the commands below:

```
$ ifconfig wlan0 xxx.xxx.xxx.xxx
$ ifconfig
```

where “xxx.xxx.xxx.xxx” is the IP address that you wish to use.

Max Performance Mode

A script designed to optimize the performance is preinstalled. Run the following commands to temporarily set the Manifold to Max Performance Mode:

```
$ sudo /home/ubuntu/max_performance
```

Add a new entry of “/home/ubuntu/max_performance” within the “/etc/rc.local” if you wish to set the Manifold into Max Performance mode persistently. Refer to <http://elinux.org/Jetson/Performance> for more information.

Installing Development Packages

Installing CUDA

1. Visit the following link to download the CUDA package: http://developer.download.nvidia.com/embedded/L4T/r21_Release_v3.0/cuda-repo-l4t-r21.3-6-5-prod_6.5-42_armhf.deb
2. Run the following commands to install the CUDA package onto the operating system.

```
$ sudo dpkg -i cuda-repo-l4t-r21.3-6-5-prod_6.5-42_armhf.deb
$ sudo apt-get update
$ sudo apt-get install cuda-toolkit-6-5
```

Refer to the link below for more details: <https://developer.nvidia.com/embedded/linux-tegra>

Installing the OpenCV4tegra

- a. Visit the following link to download the package of “libopencv4tegra-repo_l4t-r21_2.4.10.1_armhf.deb” http://developer.download.nvidia.com/embedded/OpenCV/L4T_21.2/libopencv4tegra-repo_l4t-r21_2.4.10.1_armhf.deb

b. Run the commands below to install the OpenCV4tegra package onto the operating system.

```
$ sudo dpkg -i libopencv4tegra-repo_l4t-r21_2.4.10.1_armhf.deb
$ sudo apt-get update
$ sudo apt-get install libopencv4tegra libopencv4tegra-
devlibopencv4tegra-python
```

Refer to the link below for more details: <https://developer.nvidia.com/embedded/linux-tegra>

Installing the Robotic Operating System (ROS)

Refer to the link below for the complete information about how to download and install the ROS package onto the operating system. <http://wiki.ros.org/indigo/Installation/UbuntuARM>

System Image

Prerequisites for creating the system image:

1. Linux operating system.
2. At least 16 GB of free disk space.

Downloading Package File

Download the package file "manifold_image_v1.0.tar.gz" from the following link:

<https://developer.dji.com/en/manifold/downloads/>

Unzip the package files by running the commands listed below:

```
$ mkdir ~/manifold
$ cd ~/manifold
$ sudo tar -xvpzf <your path>/manifold_image_v1.0.tar.gz
```

Entering Recovery Mode

Method 1:

1. Switch off the Manifold development board and remove the AC adapter from the power port.
2. Connect the Recovery USB to an available USB port on the Host computer with the supplied Micro USB cable.
3. Connect the power adapter to the Manifold development board.
4. Use a pin to press and hold the RECOVERY button, and then press the POWER button once to turn on the Manifold development board. Release the RECOVERY button to enter Recovery mode.

Method 2 :

1. Switch off the Manifold development board and remove the AC adapter from the power port.
2. Connect the Recovery USB to an USB Port on the Host computer via the Micro USB cable.
3. Connect the power adapter to the Manifold development board.
4. Press the power button once to boot up the system. While pressing the Recovery Button, use a pin to press and release Reset Button once. Finally, release the Recovery Button.

Run “lsusb” from the Host computer to check if the Manifold has entered the Recovery Mode successfully.

```
dji@tegra-ubuntu:~$ lsusb
Bus 001 Device 002: ID 05e3:0608 Genesys Logic, Inc. USB-2.0 4-Port HUB
Bus 001 Device 003: ID 05e3:0608 Genesys Logic, Inc. USB-2.0 4-Port HUB
Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
Bus 002 Device 001: ID 1d6b:0003 Linux Foundation 3.0 root hub
Bus 003 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
Bus 001 Device 008: ID 0955:7740 NVidia Corp.
```

The Manifold has entered Recovery Mode successfully if “NVIDIA” is displayed on the screen. If no such text is displayed, repeat steps 1 to 4.



- The Manifold development board will not boot up if it is in Recovery Mode (nothing appears on the monitor).

Create a System Image

Enter the bootloader folder by running the command shown below:

```
$ cd ~/manifold/manifold_images/bootloader
```

Remove the existing system.img file from the bootloader folder. Run the following command to create a new system image.

```
$ sudo ./nvflash --read APP system.img --bl ardbeg/fastboot.bin --go
```

It may take a while to create the system image. Please be patient. After running the above command, the “system.img” file can be used as a backup of the current system.

Restoring the System Image

Run the following command to restore the system to its default settings.

```
$ cd ~/manifold/manifold_images
$ sudo ./flash.sh jetson-tk1 mmcblk0p1
```

Restore the system with the created system.img file by executing the commands below:

```
$ cd ~/manifold/manifold_images
$ sudo ./flash.sh -r jetson-tk1 mmcblk0p1
```

Refer to video tutorial on the Manifold product page (<https://developer.dji.com/en/manifold/videos/>) for more information.

For more information about restoring system refer to this link (<http://elinux.org/Jetson/Cloning>).

Compiling Kernel

1. Download the “manifold_kernel_source_v1.0.tar.gz” source package from the Manifold product page (<https://developer.dji.com/en/manifold/downloads/>).

2. Unzip the package file by running the commands below:

```
$ mkdir ~/kernel
$ cd ~/kernel
$ tar xvfz <your path>/manifold_kernel_source_v1.0.tar.gz
```

3. Compiling kernel by running the commands below:

```
$ cd ~/kernel/Linux_3.10
$ cp arch/arm/configs/manifold_config .config
$ make menuconfig
$ make
```

Note that manifold_config is the default configuration file.

4. Run “make modules” command to install the kernel and modules.

```
$ make modules_install
$ sudo cp /boot/zImage /boot/zImage.bak //backup the zImage
$ sudo cp arch/arm/boot/zImage /boot/ //cp zImage
$ sudo cp arch/arm/boot/dts/tegra124-jetson_tk1-pm375-000-c00-00.dtb /boot/ //copy device tree
```

Specification

Weight	197 g
Dimension	110 mm×110 mm×26 mm
Processors	Quad-core, 4-Plus-1 ARM Cortex-A15 MPcore Processor with NEON technology Low-power NVIDIA Kepler-based GeForce graphics processor Image-signal processor Ultra low-power audio processor
Memory	2GB DDR3L system RAM 16 GB eMMC 4.51 storage
Network	10/100/1000BASE-T Ethernet
Audio	Combo audio jack(mic/headphone)
USB	USB 3.0 Type-A Host connector×2 USB 2.0 Type-A Host connector×2 Micro-B USB connector (host/slave mode) Extended USB connector with DJI M-series Multicopter×2
I/O	Mini-HDMI connector Half mini-PCle expansion slot UART port(3.3V)×2 Micro SD card connector I/O expansion headers (26pins)
Input Voltage	14 V ~ 26 V
Operating Temperature	-10 °C ~ 45 °C
Power Consumption	5 w ~ 15 w

This content is subject to change.

Download the latest version from
<https://developer.dji.com/manifold/downloads>

If you have any questions about this document, please contact DJI by
sending a message to **DocSupport@dji.com**.